BOSE®



RC-35S2 Remote Control

Owner's Guide | Guía de usuario | Notice d'utilisation

SAFETY AND REGULATORY INFORMATION

Please read this owner's guide

Please take the time to follow the instructions in this owner's guide carefully. It will help you set up and operate your system properly and enjoy its advanced features. Please save this owner's guide for future reference.

WARNINGS:

- *Do not expose this apparatus to dripping or splashing, and do not place objects filled with liquids, such as vases, on or near the apparatus. As with any electronic products, use care not to spill liquids into any part of the system. Liquids can cause a failure and/or a fire hazard.*
- *Do not place any naked flame sources, such as lighted candles, on or near the apparatus.*
- *Keep the remote control batteries away from children. They may cause a fire or chemical burn if mishandled. Do not recharge, disassemble, heat above 100°C (212°F), or incinerate. Dispose of used batteries promptly. Replace only with batteries of the correct type and model number.*

Please dispose of used batteries properly, following any local regulations. Do not incinerate.

For RC-35S2-27 remotes in the U.S. and Canada

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by Bose Corporation could void the user's authority to operate this equipment.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For RC-35S2-27 remotes in Canada only

This Category II radio communication device complies with Industry Canada Standard RSS-310.

For RC-35S2-27 or RC-35S2-40 remotes in Europe only

CE Bose Corporation hereby declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC and other applicable Directives. The complete Declaration of Conformity can be found at www.Bose.com/compliance.

English

INTRODUCTION

Overview

The RC-35S2 remote control is specifically designed to expand your Bose® LIFESTYLE® V25/V35 home entertainment system into another area of your home. Using the RC-35S2 remote control, you can listen to your main room system through a Bose link-enabled expansion product in another room.



RC-35S2 remote control with expansion system

Unpacking

Check the carton for the parts shown.



RC-35S2 remote control



Four AAA (IEC LR3) batteries



Homewide antenna

Save the carton and packing materials, which provide the safest way to transport this product.

If any part of the product appears to be damaged, do not attempt to use it. Contact your authorized Bose dealer immediately or call Bose Customer Service. Refer to the address list included with your LIFESTYLE® system for contact information.

EXPANDING YOUR LIFESTYLE® SYSTEM

Connecting your homewide antenna

Plug the antenna cable into the **Homewide Antenna** connector on your LIFESTYLE® system.



Because the antenna radiates at 90 degrees to the antenna (bare wire), mount the antenna vertically as close as possible to the center of the house.

Do not bundle the antenna together with other cables and do not place it close to large metallic objects or surfaces.

Connecting an expansion product to the control console

1. Plug one end of the Bose® link cable into the **Bose link OUT** connector on your LIFESTYLE® system control console.



2. Connect the other end of the Bose link cable to your expansion product.

   Your expansion product might be a speaker system or an AL8 Homewide Wireless Audio Link if you are making a wireless connection. Refer to the owner's guide that came with your expansion product for more information on making this connection.

Getting the remote ready

1. Make sure your RC-35S2 remote and expansion product are set to the same room code.

   The remote you received is set to room code B. If the expansion product is also set to room B, you do not need to do anything.

   To change the remote control room code, see "Changing the room code" on page 8.

   To change the room code in the expansion product, see the owner's guide that came with it.

2. Make sure the house code in the RC-35S2 remote is the same as in your LIFESTYLE® V25/V35 home entertainment system.

   Both products are initially set to house code 15 and should work together unless the house code in your main system was changed. To change the house code on the RC-35S2, see "Changing the house code" on page 9.

Note: *For more information on changing the house code, see "Adding Sound to Another Room" in the operating guide for your LIFESTYLE® system.*

Installing the remote batteries

1. Press and slide the battery cover off the back of the remote.



2. Install the four supplied batteries, matching the polarity markings (+ and –) on the batteries to the markings inside the battery compartment.
3. Slide the battery cover back into place until it snaps closed.

USING THE REMOTE



The RC-35S2 remote offers a simple set of controls that allow you to select sources and adjust audio playback in your expansion room.

① On/Off

Turns on/off your Bose® link expansion system.

When turning on your system, the source last selected is active.

② PARTY

PARTY

Links all connected expansion products to the source playing on your LIFESTYLE® system in the main room. Can be used during a party when the same music is desired in multiple rooms.

③ Source selection

Using the RC-35S2 remote, you can select any device set up to work with your LIFESTYLE® system.

Note: *To select any source other than AM/FM radio or an iPod, the source must be powered on.*

TV

Selects sources configured for TV viewing, such as a broadcast tuner in your TV and/or any set top boxes connected to the control console.

Each press switches to the next available source.

FM AM

Selects the last FM or AM radio station selected.

Press again to toggle between FM and AM when the radio is on.

DISC

Selects disc devices connected to the control console, such as DVD, Blu-ray Disc™, and CD players.

Each press switches to the next available source.

OTHER

Selects your iPod (if docked), other digital media players, or game consoles connected to the control console, as well as the last selected local source in the expansion room.

Each press switches to the next available source.

Note: *A local source is a device, such as a TV or a portable CD or MP3 player, that is connected directly to audio input connectors on the expansion product.*

iPod is a trademark of Apple, Inc., registered in the U.S. and other countries. All other marks are registered trademarks and trademarks of Bose Corporation.

④ Playback controls

The playback controls allow you to operate devices connected to your LIFESTYLE® system such as a DVR, DVD/CD player, and docked iPod.


Begins playback of DVR, CD/DVD, or iPod
Pauses playback of DVR, CD/DVD, or iPod
Skips to previous track or radio station
Skips to next track or radio station
Stops playback of DVR, CD/DVD, or iPod

⑤ Volume controls

+ Raises the volume and unmutes the system (if muted).

– Lowers the volume.

Mutes/unmutes expansion room speakers.

Press and hold to mute/unmute speakers in all rooms.

⑥ Channel controls

Changes to next/previous TV channel or radio preset.

If the source in use by the control console is a cable or satellite box connected to your TV, this moves to the next/previous cable or satellite channel.

Returns to last TV channel or radio station preset.

Note: *If these controls do not seem to work with your TV, you may need to plug an IR emitter cable into the IR connector on the rear panel of the control console. IR cables are available from Bose. See the address list included with your LIFESTYLE® system for contact information.*

Although the LIFESTYLE® system control console emits IR signals into the room where it is located, an IR emitter can better direct those signals to the TV.

⑦ Numeric keypad



Selects a CD track, DVD chapter, radio station preset, or TV channel that corresponds to the numbers pressed.

Enters a dash or dot as necessary for a digital TV channel number.

Confirms channel selection on certain TVs.

USING MULTI-ROOM AUDIO

Room and house codes

Room and house codes are the settings that allow you to operate your main room system from another room in your home that has a Bose® link-enabled expansion system. Each RC-35S2 remote and your main room system must have identical house codes. Also, each expansion system and the RC-35S2 remote used with it must have identical room codes.

Changing the room code

Your RC-35S2 remote is set at the factory for room code B. If room code B is already used by another Bose link product in your home, you need to change both the RC-35S2 and expansion system to another room code.

To change the room code in your RC-35S2 remote:

1. Press and slide the battery cover off the back of the remote.
2. Locate the room code switches (6-9).



3. Select a room code from the following table.

Room Code	6	7	8	9
B	—	—	—	
C		—	—	—
D	—	—	—	—
E	—		—	—
F	—	—		—
G	—	—	—	
H		—	—	—
I	—		—	—
J	—	—	—	
K	—		—	—
L	—	—	—	—
M	—	—		
N	—	—		—
O	—	—	—	

4. Using a fine-point pen or other small tool, set switches 6-9 to the corresponding up and down positions shown for that room code.

5. Slide the battery cover back into place until it snaps closed.

Changing the house code

The radio frequency (RF) signals used in expansion systems have a long range and the ability to penetrate walls. Therefore, the signals from an RC-35S2 remote in one home can possibly reach and affect the operation of a LIFESTYLE® system in a nearby home. Changing the house code for the system and all the remotes used with it avoids possible conflict.

Your RC-35S2 remote is set at the factory for house code 15.

To change the house code in your RC-35S2 remote and in your LIFESTYLE® system:

1. Press and slide the battery cover off the back of the remote.

2. Locate the house code switches (1-4).



3. Select a house code from the following table.

House Code	1	2	3	4
0	—	—	—	—
1	—	—	—	
2	—	—		—
3	—	—		
4	—		—	—
5	—			
6	—			—
7				
8		—	—	—
9				—
10				—
11			—	
12			—	—
13				—
14				
15				

4. Using a fine-point pen or other small tool, set switches 1-4 to the corresponding up and down positions shown for that house code.
5. Slide the battery cover back into place until it snaps closed.
6. Go to the main room and press the Setup button on the control console.
7. Select Homewide.
8. Select the Standard house code mode.
9. Return to the expansion room and press the Stop button (■) on the RC-35S2 remote.

The house code in your LIFESTYLE® system is now the same as in the RC-35S2 remote control.

REFERENCE

Troubleshooting

Problem	What to do
System not responding to controls	• Make sure the RC-35S2 remote and the main room system have the same house code. See "Getting the remote ready" on page 3. • Make sure the RC-35S2 remote and the expansion system have the same room code. See "Getting the remote ready" on page 3.
A device is not responding to remote control commands	• Make sure the device is on. • Install an IR blaster in the main room.
Intermittent operation using the RC-35S2 remote	• Check the batteries to see if they need changing. • Move the remote to a different location to see if the problem is simply caused by "dead spots" in the building.
System turns on or off, or changes sources unexpectedly when no buttons on the RC-35S2 remote have been pressed	• Check to see if someone in the main room is using the primary remote control in that way. • You may be experiencing a control conflict with another LIFESTYLE® system near your home. Change the house code. See "Changing the house code" on page 9.

Customer service

For questions about the RC-35S2 remote or LIFESTYLE® system expansion, contact your local Bose dealer.

To contact Bose directly, see the address list included with your LIFESTYLE® system or visit http://owners.Bose.com.

Technical information

Remote control range: 65 ft (20 m)

Size: 1.0"H x 2.3"W x 7.7"L
(2.5 cm x 5.8 cm x 19.5 cm)

Weight: 6.9 oz (195 g)

Battery type: AAA or IEC-LR3 1.5V batteries (4)

Frequency: U.S./Canada/other: 27.145 MHz
EU/other: 40.685 MHz



BOSE®

Better sound through research®

©2010 Bose Corporation, The Mountain,
Framingham, MA 01701-9168 USA
AM324085 Rev.01

BOSE®

Warranty information inside
Register your product now

Contiene información sobre la garantía
Registre su producto ahora

Renseignements sur la garantie à l'intérieur
Enregistrez votre produit dès maintenant

BOSE®

Better sound through research®

Serial number:

Número de serie:

Numéro de série :

©2010 Bose Corporation. C_007933 AM324486 _02

324486-0010

Registre su producto:* Conozca toda la gama de servicios que su garantía le ofrece.

Registrarse en línea es fácil y rápido.
Global.Bose.com/register

Enlace directo para registrarse:

www.register.Bose.eu *(Europa)*
www.Bose.com/register *(EE.UU., Puerto Rico e Islas Vírgenes de EE.UU.)*
www.Bose.com.au/warranty *(Australia)*
www.Bose.ca/register *(Canadá)*
www.Bose.co.nz/warranty *(Nueva Zelanda)*

Envíe cualquier correspondencia en relación con información de productos o los servicios de la Garantía limitada a la sede corporativa de la empresa en:

Registro del producto
Bose Corporation
The Mountain
PO Box 9168
Framingham, MA 01701-9168 EE.UU.

1-800-736-5076 (EE.UU.)
1-508-766-1000 (INTL) *Es posible que se apliquen cargos por la llamada. Tenga a mano el número de serie cuando realice la llamada.*

Los propietarios que vivan fuera de los Estados Unidos deben revisar la Guía del usuario o ir a Global.Bose.com para encontrar la dirección más cercana.

GARANTÍA LIMITADA

A quién cubre:
Esta garantía se extiende únicamente al comprador final original o a la persona que reciba el producto como regalo y no se extenderá a cualquier otra persona o beneficiario.

Qué se cubre/Por cuánto tiempo:
A menos que un período de garantía diferente se explicite en la Guía del usuario provista con su producto Bose®, por un período de 1 año (2 años en la UE.) [5 años para altavoces no eléctricos incorporados en el producto] a partir de la fecha de la compra minorista por parte del usuario final original, Bose garantiza que este producto, cuando se le entrega en su paquete original y en nueva condición, por parte de un revendedor autorizado por Bose y es utilizado en condiciones normales, no tiene defectos de fabricación, de materiales ni de producción.

Qué es lo que no se cubre:
Esta garantía no cubre defectos ocasionados por prácticas de uso o mantenimiento incorrectas o no razonables, el incumplimiento de las instrucciones de uso; accidentes; humedad excesiva; insectos; rayos; subidas de tensión; conexión a voltaje incorrecto; alteraciones o modificaciones no autorizadas del producto original; daños causados por embalaje o proceso de envío inapropiado; pérdida, daño o alteración de la información guardada; daños ocasionados por el uso con productos que no sean de Bose; productos que requieren de modificación o adaptación para permitir que se utilicen en cualquier país fuera del país para el que fueron diseñados, fabricados, aprobados y/o autorizados, o reparación de productos dañados por estas modificaciones; y productos adquiridos de vendedores no autorizados.

Qué haremos:
Durante el período de garantía repararemos o sustituiremos, a nuestra discreción, las partes defectuosas en un período razonable de tiempo y sin cargo utilizando repuestos nuevos o rehabilitada.

Qué es lo que no haremos:
Pagar cargos por envío, seguros o transporte del producto de usted a nosotros, tasas de importación o impuestos.

Qué debe hacer para obtener el servicio de la Garantía limitada:
Devuelva el producto con el comprobante de compra emitido por un vendedor autorizado de Bose, realizando los siguientes pasos:

1. Contáctese con la compañía Bose en su país/región (visite Global.Bose.com para obtener información de contacto en su país/región) a fin de obtener instrucciones específicas sobre devolución y envío;
2. Rotule y envíe el producto, con flete pago, a la dirección de la compañía Bose en su país; y
3. Coloque cualquier número de autorización para la devolución que sea necesario en forma visible y en la parte exterior del paquete. Los paquetes que no tengan un número de autorización de devolución, cuando sea necesario, serán rechazados.

Otras condiciones:
LAS DISPOSICIONES DE ESTA GARANTÍA LIMITADA REEMPLAZAN CUALQUIER OTRA GARANTÍA, YA SEA EXPRESA O IMPLÍCITA, ESCRITA U ORAL, INCLUYENDO CUALQUIER GARANTÍA DE COMERCIABILIDAD O ADECUACIÓN A UN FIN PARTICULAR. LA RESPONSABILIDAD MÁXIMA DE BOSE CORPORATION NO PUEDE EXCEDER EL PRECIO DE COMPRA REAL QUE USTED PAGÓ POR EL PRODUCTO. BAJO NINGUNA CIRCUNSTANCIA SERÁ BOSE RESPONSABLE POR LA PÉRDIDA, DAÑO O ALTERACIÓN DE INFORMACIÓN GUARDADA O POR DAÑOS ESPECIALES, INCIDENTALES, EN CONSECUENCIA O INDIRECTOS CUALQUIERA SEA LA CAUSA DE LOS MISMOS, INCLUYENDO SIN LIMITACIÓN, EL REEMPLAZO DE EQUIPOS Y PROPIEDADES Y CUALQUIER COSTO DE RECUPERACIÓN, PROGRAMACIÓN O REPRODUCCIÓN DE CUALQUIER PROGRAMA O INFORMACIÓN GUARDADA O UTILIZADA CON SU PRODUCTO BOSE. Esta garantía se anula en caso de que la etiqueta con el número de serie haya sido quitada o dañada.

Otros derechos legales:
Esta garantía limitada le otorga derechos legales específicos y es posible que también se le otorguen otros derechos que varían según los estados o países. Algunos lugares no permiten limitaciones en garantías implícitas o la exclusión o limitación por daños secundarios o resultantes, por lo que es posible que las limitaciones o exclusiones anteriores no se apliquen a usted.

**En caso de que no registre su producto no se verán afectados sus derechos de garantía limitada.*

Enregistrez votre produit:* Renseignez-vous sur la gamme complète de services offerts dans le cadre de notre garantie.

L'enregistrement en ligne est simple et rapide.
Global.Bose.com/register

Liens directs vers les sites d'enregistrement :

www.register.Bose.eu *(Europe)*
www.Bose.com/register *(États-Unis, Puerto Rico et Îles Vierges des États-Unis)*
www.Bose.com.au/warranty *(Australie)*
www.Bose.ca/register *(Canada)*
www.Bose.co.nz/warranty *(Nouvelle-Zélande)*

Pour toute correspondance relevant d'une demande de renseignements au sujet de nos produits ou de nos services de garantie limitée, veuillez nous écrire à notre siège social, à l'adresse suivante :

Enregistrement de produits
Bose Corporation
The Mountain
PO Box 9168
Framingham, MA 01701-9168 États-Unis

1-800-736-5076 (États-Unis)
1-508-766-1000 (international) *Des frais peuvent s'appliquer. Veuillez avoir en main votre numéro de série lors de l'appel.*

Si vous résidez hors des États-Unis, consultez le guide de l'utilisateur ou le Global.Bose.com pour obtenir l'adresse postale la plus proche.

GARANTIE LIMITÉE

Bénéficiaire :
La présente garantie est uniquement valable pour le premier acheteur ou la personne ayant reçu le produit en cadeau et ne peut en aucun cas être étendue ou transférée à une autre personne.

Objet et durée de la garantie :
À moins qu'une durée différente ne soit indiquée dans le guide de l'utilisateur fourni avec le produit, Bose® garantit pendant une période d'un an (deux ans dans l'UE) [cinq ans pour tout haut-parleur non amplifié intégré au produit], à partir de la date d'achat au détail par le premier acheteur, que le produit est libre de tout vice de matériaux et de fabrication lorsqu'il est livré à l'état neuf, dans son emballage d'origine et par un détaillant autorisé Bose, et qu'il est utilisé dans des conditions normales.

Exclusions :
La présente garantie ne couvre pas : les défauts ou dommages résultant d'une utilisation ou d'un entretien inapproprié ou incorrect, du non-respect des directives d'utilisation, d'un accident, d'une humidité excessive, de la présence d'insectes, de la foudre, d'une pointe de courant électrique, d'un raccordement à un courant électrique d'une tension incorrecte, d'une altération ou d'une modification du produit, de procédures d'emballage ou d'expédition inappropriées; la perte, l'altération ou la détérioration de données informatiques; les dommages causés par l'utilisation avec un produit d'une marque autre que Bose; les modifications ou adaptations effectuées au produit pour qu'il soit utilisable dans un pays autre que celui pour lequel il a été conçu, fabriqué, approuvé et/ou autorisé, de même que la réparation d'un produit endommagé par ces modifications; les produits achetés auprès d'un détaillant non agréé.

Notre engagement :
Au cours de la période de garantie, à notre seule discrétion, nous réparerons ou remplacerons toute pièce défectueuse dans un délai raisonnable, sans frais utilisant nouvel ou rénové les parties de remplacement.

Frais exclus :
La garantie ne couvre pas le paiement des frais d'expédition, d'assurance et de transport du produit vers notre adresse, ainsi que de toutes taxes et de tous droits d'importation ou autres.

Conditions de l'obtention des services de garantie limitée réparation :
Expédiez-nous le produit, accompagné de la preuve d'achat d'origine d'un détaillant Bose autorisé, en suivant les directives ci-dessous :

1. Communiquez avec l'entité Bose de votre pays ou région (consultez le site Global.Bose.com pour connaître les coordonnées de Bose dans votre pays ou région) pour obtenir les instructions de retour et d'expédition particulières;
2. Étiquetez et expédiez le produit, en port payé, à l'adresse fournie par l'entité Bose de votre pays ou région; et
3. Inscrivez de façon très visible sur l'extérieur de l'emballage tout numéro d'autorisation de retour nécessaire. Un envoi qui ne comporte pas de numéro d'autorisation de retour lorsque celui-ci est requis sera refusé.

Autres conditions :
LES CONDITIONS DE LA PRÉSNTE GARANTIE LIMITÉE REMPLACENT TOUTE AUTRE GARANTIE, EXPRESSE OU IMPLICITE, EXPRIMÉE PAR ÉCRIT OU ORALEMENT, Y COMPRIS TOUTE GARANTIE DE QUALITÉ MARCHANDE OU D'ADAPTATION À UN USAGE PARTICULIER. LA RESPONSABILITÉ MAXIMALE DE BOSE CORPORATION ÉQUIVAUT AU PRIX PAYÉ PAR LE CONSOMMATEUR À L'ACHAT DU PRODUIT. BOSE NE PEUT EN AUCUN CAS ÊTRE TENUE RESPONSABLE DE LA PERTE, DE L'ALTÉRATION OU DE LA DÉTÉRIOATION DE DONNÉES INFORMATIQUES, NI DE DOMMAGES PARTICULIERS, ACCESSOIRES OU INDIRECTS, QUELLE QU'EN SOIT LA CAUSE, Y COMPRIS, SANS RESTRICTION, LE REMPLACEMENT D'ÉQUIPEMENT ET DE BIENS ET TOUS FRAIS DE RÉCUPÉRATION, DE PROGRAMMATION OU DE REPRODUCTION DE TOUT PROGRAMME OU DE TOUTES DONNÉES ENREGISTRÉS DANS LE PRODUIT BOSE OU UTILISÉS AVEC CELUI-CI. La présente garantie est annulée si l'étiquette portant le numéro de série est retirée ou altérée.

Autres droits :
La présente garantie limitée vous confère des droits particuliers selon la loi; vous pouvez aussi bénéficier d'autres droits qui varient selon votre pays ou région de résidence. Certains territoires ne permettant pas la limitation des garanties implicites ou l'exclusion ou la limitation des dommages indirects ou accessoires, il est donc possible que les limites ou exclusions ci-dessus ne s'appliquent pas à vous.

**Le non-enregistrement du produit n'affecte aucunement vos droits en vertu de la garantie limitée.*

Register your product.* Learn about the full range of services your warranty provides.

Registering online is quick and easy!
Global.Bose.com/register

To link directly to registration:

www.register.Bose.eu *(Europe)*
www.Bose.com/register *(US, PR & USVI)*
www.Bose.com.au/warranty *(Australia)*
www.Bose.ca/register *(Canada)*
www.Bose.co.nz/warranty *(New Zealand)*

Send any correspondence regarding product information or Limited Warranty services to our corporate headquarters at:

Product Registration
Bose Corporation
The Mountain
PO Box 9168
Framingham, MA 01701-9168 USA

1-800-736-5076 (US)
1-508-766-1000 (INTL) *Charges may apply.*
Please have your serial number available when you call.

Owners living outside the United States should check the Owner's Guide or Global.Bose.com for the nearest mailing address.

LIMITED WARRANTY

Who is covered:
This warranty is extended only to the original end-use purchaser or the person receiving the product as a gift, and shall not be extended to any other person or transferee.

What is covered/For how long:
Unless a different warranty period is stated in the Owner's Guide provided with your Bose® product, for a period of 1 year (2 years EU) [5 years for any non-powered speakers that may be incorporated into this product] from the date of retail purchase by the original end-use purchaser, Bose warrants that this product, when delivered to you in new condition, in original packaging, from a Bose authorized reseller and used in normal conditions, is free from any defects in manufacturing, materials and workmanship.

What is not covered:
This warranty does not cover defects resulting from improper or unreasonable use or maintenance; failure to follow operating instructions; accident; excess moisture; insects; lightning; power surges; connections to improper voltage supply; unauthorized alteration or modification of original condition; damages caused by inadequate packing or shipping procedures; loss of, damage to or corruption of stored data; damages caused by use with non-Bose products; product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications; and products purchased from unauthorized dealers.

What we will do:
During the warranty period, we will, at our sole option, repair or replace (using new or refurbished replacement parts) any defective parts within a reasonable period of time and free of charge.

What we will not do:
Pay shipping, insurance or transportation charges from you to us, or any import fees, duties and taxes.

What you must do to obtain Limited Warranty Service:
Return product, with proof of purchase from an authorized Bose dealer, using the following procedures:

1. Contact the Bose organization in your country/region (visit Global.Bose.com for Bose contact information in your country/region) for specific return and shipping instructions;
2. Label and ship the product, freight prepaid, to the address provided by the Bose organization in your country; and
3. Place any necessary return authorization number prominently on the outside of the carton. Cartons not bearing a return authorization number, where required, will be refused.

Other conditions:
THE PROVISIONS OF THIS LIMITED WARRANTY ARE IN LIEU OF ANY OTHER WARRANTY, WHETHER EXPRESSED OR IMPLIED, WRITTEN OR ORAL, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. BOSE CORPORATION'S MAXIMUM LIABILITY SHALL NOT EXCEED THE ACTUAL PURCHASE PRICE PAID BY YOU FOR THE PRODUCT. IN NO EVENT SHALL BOSE BE LIABLE FOR LOSS OF, DAMAGE TO OR CORRUPTION OF STORED DATA, OR FOR SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR INDIRECT DAMAGES HOWSOEVER CAUSED INCLUDING WITHOUT LIMITATION THE REPLACEMENT OF EQUIPMENT AND PROPERTY, AND ANY COSTS OF RECOVERING, PROGRAMMING OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH YOUR BOSE PRODUCT. This warranty is void if the label bearing the serial number has been removed or defaced.

Other legal rights:
This limited warranty gives you specific legal rights, and you also may have other rights that vary from state to state or country to country. Some places do not allow limitations on implied warranties or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

**Failure to register your product will not affect your limited warranty rights.*